FanSync™

Your Team. Your Gear. Connected.

WASHINGTON STATE COUGARS EDITION

Set up your Coug in 3 easy steps

It takes about 5 minutes. You'll need your phone or laptop and your home Wi-Fi password.

BEFORE YOU START

2.4 GHz Wi-Fi
Most routers offer it. One name for both bands is fine.

Your Wi-Fi password
Have it handy for step 2.

A phone or laptop
To join your FanSync's own Wi-Fi.

Not supported: school, dorm or work Wi-Fi that asks for a username (WPA2-Enterprise). Use a home router or a phone hotspot.

1 Power up and join GoCougsAP

Plug in your Coug. Solid yellow lights mean it's ready for setup. On your phone or laptop, open Wi-Fi settings and join **GoCougsAP**. It has no password.



Solid yellow
Ready for setup



2 Tell it your home Wi-Fi

A setup page opens by itself. Tap **Configure WiFi**, choose your home network, type its password, and tap **Save**. Your Coug restarts.

Page didn't open? Open a web browser on your phone and go to **192.168.4.1**.





3 Watch for the blink

When it connects, the lights blink red and white for about 2 seconds, then glow steady white until your team wins. Then reconnect your phone to your usual Wi-Fi.



Solid yellow
Ready for setup



Blinks red & white
Connected!



Steady white
All set

Connected? Turn over to make it yours. **http://gocougs.local**

Need help? fansync.net/us/setup

Make it yours

Your Coug has its own settings page. Open it from any phone or computer on your Wi-Fi.

OPEN THIS ADDRESS IN ANY WEB BROWSER

http://gocougs.local

Tip: bookmark it, or add it to your phone's home screen.



GOOD TO KNOW

Changes light up right away. Press **Save** at the bottom of the page to keep them after a restart.

Your FanSync checks for results about every 5 minutes.

After a power cut it reconnects on its own.

What you can change

1. **Brightness**
   Set how bright it glows with no win, and how bright for a win.

2. **Lighting scheme**
   Light the logo in team colors on a win, or choose Holiday, custom colors, or random patterns.

3. **Sports**
   Pick which sports light it up.

4. **Time zone and sleep**
   Set your time zone, then pick quiet hours when the lights dim.

If something isn't right

Lights stay solid yellow
It hasn't joined Wi-Fi yet. Repeat steps 1–2 and check the password and that your network is 2.4 GHz.

Can't find GoCougsAP
Check it's plugged in and glowing yellow, move closer, and refresh your Wi-Fi list.

The setup page doesn't open
Stay on GoCougsAP, open a web browser and go to 192.168.4.1. Try turning off mobile data.

gocougs.local won't open
Use a device on the same Wi-Fi. Some phones can't open .local addresses; find the device's IP address in your router's list of connected devices and type that instead.

I changed my Wi-Fi password
Repeat steps 1–3 to give it the new one.

School, dorm or work Wi-Fi
Networks that ask for a username aren't supported. Use a home router or a phone hotspot.

FanSync™ is powered by Sports IoT™ LLC. © 2019–2026 Sports IoT LLC. Sports IoT LLC intellectual property: sports-iot.com/innovation